

Einbauliste von EBC DP2103 - bei Fragen wenden sie sich an www.ebcbremsen.ch; info@equipe-bachofner.ch; Telefon 052 511 18 70

DP2103 is suitable for the following vehicles...

This part will fit all of the vehicles listed below. For more detail on the position it fits on your vehicle, advice notes and further parts, select your vehicle from the list

DP2103 eignet sich für folgende Fahrzeuge:

Dieses Teil passt auf alle unten aufgeführten Fahrzeuge. Für weitere Details zur Einbauposition an Ihrem Fahrzeug, wichtige Hinweise und ergänzende Teile wählen Sie bitte Ihr Fahrzeug aus der Liste aus.

Make	Model	Sub-Model	Engine	Valves	BHP	Year	Fitment Details
ALFA ROMEO	1750 GTV		1.75 Petrol			1967	To Fit Front
ALFA ROMEO	1750 GTV		1.75 Petrol			1968	To Fit Front
ALFA ROMEO	1750 GTV		1.75 Petrol			1969	To Fit Front
ALFA ROMEO	1750 GTV		1.75 Petrol			1970	To Fit Front
ALFA ROMEO	1750 GTV		1.75 Petrol			1971	To Fit Front
ALFA ROMEO	2000 GTV		2.00 Petrol			1971	To Fit Front
ALFA ROMEO	2000 GTV		2.00 Petrol			1972	To Fit Front
ALFA ROMEO	2000 GTV		2.00 Petrol			1973	To Fit Front
ALFA ROMEO	2000 GTV		2.00 Petrol			1974	To Fit Front
ALFA ROMEO	2000 GTV		2.00 Petrol			1975	To Fit Front
ALFA ROMEO	2000 GTV		2.00 Petrol			1976	To Fit Front
ALFA ROMEO	Berlina 1750		1.75 Petrol			1968	To Fit Front
ALFA ROMEO	Berlina 1750		1.75 Petrol			1969	To Fit Front
ALFA ROMEO	Berlina 1750		1.75 Petrol			1970	To Fit Front
ALFA ROMEO	Berlina 1750		1.75 Petrol			1971	To Fit Front
ALFA ROMEO	Berlina 1750		1.75 Petrol			1972	To Fit Front
ALFA ROMEO	Berlina 2000		2.00 Petrol			1971	To Fit Front
ALFA ROMEO	Berlina 2000		2.00 Petrol			1972	To Fit Front
ALFA ROMEO	Berlina 2000		2.00 Petrol			1973	To Fit Front
ALFA ROMEO	Berlina 2000		2.00 Petrol			1974	To Fit Front
ALFA ROMEO	Berlina 2000		2.00 Petrol			1975	To Fit Front
ALFA ROMEO	Berlina 2000		2.00 Petrol			1976	To Fit Front
ALFA ROMEO	Berlina 2000		2.00 Petrol			1977	To Fit Front
ALFA ROMEO	Montreal		2.60 Petrol		194	1970	To Fit Front
ALFA ROMEO	Montreal		2.60 Petrol		194	1971	To Fit Front
ALFA ROMEO	Montreal		2.60 Petrol		194	1972	To Fit Front
ALFA ROMEO	Montreal		2.60 Petrol		194	1973	To Fit Front
ALFA ROMEO	Montreal		2.60 Petrol		194	1974	To Fit Front
ALFA ROMEO	Montreal		2.60 Petrol		194	1975	To Fit Front
ALFA ROMEO	Montreal		2.60 Petrol		194	1976	To Fit Front
ALFA ROMEO	Montreal		2.60 Petrol		194	1977	To Fit Front

ALFA ROMEO	Spider		1.75 Petrol		1967 To Fit Front
ALFA ROMEO	Spider		1.75 Petrol		1968 To Fit Front
ALFA ROMEO	Spider		1.75 Petrol		1969 To Fit Front
ALFA ROMEO	Spider		1.75 Petrol		1970 To Fit Front
ALFA ROMEO	Spider		1.75 Petrol		1971 To Fit Front
ALFA ROMEO	Spider		1.75 Petrol		1972 To Fit Front
ALFA ROMEO	Spider		1.75 Petrol		1973 To Fit Front
ALFA ROMEO	Spider		2.00 Petrol		1971 To Fit Front
ALFA ROMEO	Spider		2.00 Petrol		1972 To Fit Front
ALFA ROMEO	Spider		2.00 Petrol		1973 To Fit Front
ALFA ROMEO	Spider		2.00 Petrol		1974 To Fit Front
ALFA ROMEO	Spider		2.00 Petrol		1975 To Fit Front
ALFA ROMEO	Spider		2.00 Petrol		1976 To Fit Front
ALFA ROMEO	Spider		2.00 Petrol		1977 To Fit Front
ALFA ROMEO	Spider		2.00 Petrol		1978 To Fit Front
ALFA ROMEO	Spider		2.00 Petrol		1979 To Fit Front
ALFA ROMEO	Spider		2.00 Petrol		1980 To Fit Front
ALFA ROMEO	Spider		2.00 Petrol		1981 To Fit Front
ALFA ROMEO	Spider		2.00 Petrol		1982 To Fit Front
ALFA ROMEO	Spider		2.00 Petrol		1983 To Fit Front
ALFA ROMEO	Spider		2.00 Petrol		1984 To Fit Front
ALFA ROMEO	Spider		2.00 Petrol		1985 To Fit Front
ALFA ROMEO	Spider		2.00 Petrol		1986 To Fit Front
ALFA ROMEO	Spider		2.00 Petrol		1987 To Fit Front
ALFA ROMEO	Spider		2.00 Petrol		1988 To Fit Front
ALFA ROMEO	Spider		2.00 Petrol		1989 To Fit Front
ALFA ROMEO	Spider		2.00 Petrol		1990 To Fit Front
ALFA ROMEO	Spider		2.00 Petrol		1991 To Fit Front
ALFA ROMEO	Spider		2.00 Petrol		1992 To Fit Front
ALFA ROMEO	Spider		2.00 Petrol		1993 To Fit Front
BITTER	CD		5.40 Petrol		1973 To Fit Front
BITTER	CD		5.40 Petrol		1974 To Fit Front
BITTER	CD		5.40 Petrol		1975 To Fit Front
BITTER	CD		5.40 Petrol		1976 To Fit Front
BITTER	CD		5.40 Petrol		1977 To Fit Front
BITTER	CD		5.40 Petrol		1978 To Fit Front
BITTER	CD		5.40 Petrol		1979 To Fit Front
BMW		1800 Ti/SA	1.80 Petrol	130	1964 To Fit Front
BMW		1800 Ti/SA	1.80 Petrol	130	1965 To Fit Front
BMW	2000C		2.00 Petrol		1965 To Fit Front
BMW	2000C		2.00 Petrol		1966 To Fit Front

BMW	2000C	2.00 Petrol	1967 To Fit Front
BMW	2000C	2.00 Petrol	1968 To Fit Front
BMW	2000C	2.00 Petrol	1969 To Fit Front
BMW	2000CS	2.00 Petrol	1965 To Fit Front
BMW	2000CS	2.00 Petrol	1966 To Fit Front
BMW	2000CS	2.00 Petrol	1967 To Fit Front
BMW	2000CS	2.00 Petrol	1968 To Fit Front
BMW	2000CS	2.00 Petrol	1969 To Fit Front
FERRARI	208	2.00 Petrol	1975 To Fit Front
FERRARI	208	2.00 Petrol	1976 To Fit Front
FERRARI	208	2.00 Petrol	1977 To Fit Front
FERRARI	208	2.00 Petrol	1978 To Fit Front
FERRARI	208	2.00 Petrol	1979 To Fit Front
FERRARI	208	2.00 Petrol	1980 To Fit Front
FERRARI	208	2.00 Petrol	1981 To Fit Front
FERRARI	208	2.00 Petrol	1982 To Fit Front
FERRARI	365 GTC	4.40 Petrol	1968 To Fit Rear
FERRARI	365 GTC	4.40 Petrol	1969 To Fit Rear
FERRARI	365 GTC	4.40 Petrol	1970 To Fit Rear
FERRARI	365 GTS	4.40 Petrol	1968 To Fit Rear
FERRARI	365 GTS	4.40 Petrol	1969 To Fit Rear
FERRARI	365 GTS	4.40 Petrol	1970 To Fit Rear
FERRARI	Mondial	2.90 Petrol	214 1980 To Fit Front
FERRARI	Mondial	2.90 Petrol	214 1981 To Fit Front
FERRARI	Mondial	2.90 Petrol	214 1982 To Fit Front
GLAS	2600 GT	2.60 Petrol	1965 To Fit Front
GLAS	2600 GT	2.60 Petrol	1966 To Fit Front
GLAS	2600 GT	2.60 Petrol	1967 To Fit Front
GLAS	3000 GT	3.00 Petrol	1967 To Fit Front
GLAS	3000 GT	3.00 Petrol	1968 To Fit Front
LANCIA	Stratos	2.40 Petrol	1973 To Fit Front
LANCIA	Stratos	2.40 Petrol	1974 To Fit Front
LANCIA	Stratos	2.40 Petrol	1975 To Fit Front
MERCEDES-BENZ	600 Pullman (W100)	6.30 Petrol	1963 To Fit Rear
MERCEDES-BENZ	600 Pullman (W100)	6.30 Petrol	1964 To Fit Rear
MERCEDES-BENZ	600 Pullman (W100)	6.30 Petrol	1965 To Fit Rear
MERCEDES-BENZ	600 Pullman (W100)	6.30 Petrol	1966 To Fit Rear
MERCEDES-BENZ	600 Pullman (W100)	6.30 Petrol	1967 To Fit Rear
MERCEDES-BENZ	600 Pullman (W100)	6.30 Petrol	1968 To Fit Rear
MERCEDES-BENZ	600 Pullman (W100)	6.30 Petrol	1969 To Fit Rear
MERCEDES-BENZ	600 Pullman (W100)	6.30 Petrol	1970 To Fit Rear

MERCEDES-BENZ	600 Pullman (W100)	6.30 Petrol	1971 To Fit Rear
MERCEDES-BENZ	600 Pullman (W100)	6.30 Petrol	1972 To Fit Rear
MERCEDES-BENZ	600 Pullman (W100)	6.30 Petrol	1973 To Fit Rear
MERCEDES-BENZ	600 Pullman (W100)	6.30 Petrol	1974 To Fit Rear
MERCEDES-BENZ	600 Pullman (W100)	6.30 Petrol	1975 To Fit Rear
MERCEDES-BENZ	600 Pullman (W100)	6.30 Petrol	1976 To Fit Rear
MERCEDES-BENZ	600 Pullman (W100)	6.30 Petrol	1977 To Fit Rear
MERCEDES-BENZ	600 Pullman (W100)	6.30 Petrol	1978 To Fit Rear
MERCEDES-BENZ	600 Pullman (W100)	6.30 Petrol	1979 To Fit Rear
MERCEDES-BENZ	600 Pullman (W100)	6.30 Petrol	1980 To Fit Rear
MERCEDES-BENZ	600 Pullman (W100)	6.30 Petrol	1981 To Fit Rear
MERCEDES-BENZ	R107	350 SL Petrol	1971 To Fit Front
MERCEDES-BENZ	R107	350 SL Petrol	1972 To Fit Front
MERCEDES-BENZ	R107	350 SLC Petrol	1971 To Fit Front
MERCEDES-BENZ	R107	350 SLC Petrol	1972 To Fit Front
MERCEDES-BENZ	R113	230 SL Petrol	1963 To Fit Front
MERCEDES-BENZ	R113	230 SL Petrol	1964 To Fit Front
MERCEDES-BENZ	R113	230 SL Petrol	1965 To Fit Front
MERCEDES-BENZ	R113	250SL Petrol	1966 To Fit Front
MERCEDES-BENZ	R113	250SL Petrol	1967 To Fit Front
MERCEDES-BENZ	R113	250SL Petrol	1968 To Fit Front
MERCEDES-BENZ	R113	280 SL Petrol	1967 To Fit Front
MERCEDES-BENZ	R113	280 SL Petrol	1968 To Fit Front
MERCEDES-BENZ	R113	280 SL Petrol	1969 To Fit Front
MERCEDES-BENZ	R113	280 SL Petrol	1970 To Fit Front
MERCEDES-BENZ	R113	280 SL Petrol	1971 To Fit Front
MERCEDES-BENZ	W108	250 S Petrol	1965 To Fit Front
MERCEDES-BENZ	W108	250 S Petrol	1966 To Fit Front
MERCEDES-BENZ	W108	250 S Petrol	1967 To Fit Front
MERCEDES-BENZ	W108	250 S Petrol	1968 To Fit Front
MERCEDES-BENZ	W108	250 S Petrol	1969 To Fit Front
MERCEDES-BENZ	W108	250 SE Petrol	1965 To Fit Front
MERCEDES-BENZ	W108	250 SE Petrol	1966 To Fit Front
MERCEDES-BENZ	W108	250 SE Petrol	1967 To Fit Front
MERCEDES-BENZ	W108	250 SE Petrol	1968 To Fit Front
MERCEDES-BENZ	W108	280 S Petrol	1967 To Fit Front
MERCEDES-BENZ	W108	280 S Petrol	1968 To Fit Front
MERCEDES-BENZ	W108	280 S Petrol	1969 To Fit Front
MERCEDES-BENZ	W108	280 S Petrol	1970 To Fit Front
MERCEDES-BENZ	W108	280 S Petrol	1971 To Fit Front
MERCEDES-BENZ	W108	280 S Petrol	1972 To Fit Front

MERCEDES-BENZ	W108	280 SE	Petrol	1967 To Fit Front
MERCEDES-BENZ	W108	280 SE	Petrol	1968 To Fit Front
MERCEDES-BENZ	W108	280 SE	Petrol	1969 To Fit Front
MERCEDES-BENZ	W108	280 SE	Petrol	1970 To Fit Front
MERCEDES-BENZ	W108	280 SE	Petrol	1971 To Fit Front
MERCEDES-BENZ	W108	280 SE	Petrol	1972 To Fit Front
MERCEDES-BENZ	W108	280 SEL	Petrol	1968 To Fit Front
MERCEDES-BENZ	W108	280 SEL	Petrol	1969 To Fit Front
MERCEDES-BENZ	W108	280 SEL	Petrol	1970 To Fit Front
MERCEDES-BENZ	W108	280 SEL	Petrol	1971 To Fit Front
MERCEDES-BENZ	W108	280 SEL	3.50 Petrol	1971 To Fit Front
MERCEDES-BENZ	W108	280 SEL	3.50 Petrol	1972 To Fit Front
MERCEDES-BENZ	W108	300 Seb	Petrol	1965 To Fit Front
MERCEDES-BENZ	W108	300 Seb	Petrol	1966 To Fit Front
MERCEDES-BENZ	W108	300 Seb	Petrol	1967 To Fit Front
MERCEDES-BENZ	W109	300 SEL	Petrol	1965 To Fit Front
MERCEDES-BENZ	W109	300 SEL	Petrol	1966 To Fit Front
MERCEDES-BENZ	W109	300 SEL	Petrol	1967 To Fit Front
MERCEDES-BENZ	W109	300 SEL	2.80 Petrol	1967 To Fit Front
MERCEDES-BENZ	W109	300 SEL	2.80 Petrol	1968 To Fit Front
MERCEDES-BENZ	W109	300 SEL	2.80 Petrol	1969 To Fit Front
MERCEDES-BENZ	W109	300 SEL	2.80 Petrol	1970 To Fit Front
MERCEDES-BENZ	W109	300 SEL	3.50 Petrol	1969 To Fit Front
MERCEDES-BENZ	W109	300 SEL	3.50 Petrol	1970 To Fit Front
MERCEDES-BENZ	W109	300 SEL	3.50 Petrol	1971 To Fit Front
MERCEDES-BENZ	W109	300 SEL	3.50 Petrol	1972 To Fit Front
MERCEDES-BENZ	W109	300 SEL	6.30 Petrol	1967 To Fit Front
MERCEDES-BENZ	W109	300 SEL	6.30 Petrol	1968 To Fit Front
MERCEDES-BENZ	W109	300 SEL	6.30 Petrol	1969 To Fit Front
MERCEDES-BENZ	W109	300 SEL	6.30 Petrol	1970 To Fit Front
MERCEDES-BENZ	W109	300 SEL	6.30 Petrol	1971 To Fit Front
MERCEDES-BENZ	W109	300 SEL	6.30 Petrol	1972 To Fit Front
MERCEDES-BENZ	W110	190 D	Petrol	1959 To Fit Front
MERCEDES-BENZ	W110	190 D	Petrol	1960 To Fit Front
MERCEDES-BENZ	W110	190 D	Petrol	1961 To Fit Front
MERCEDES-BENZ	W110	190 D	Petrol	1962 To Fit Front
MERCEDES-BENZ	W110	190 D	Petrol	1963 To Fit Front
MERCEDES-BENZ	W110	190 D	Petrol	1964 To Fit Front
MERCEDES-BENZ	W110	190 D	Petrol	1965 To Fit Front
MERCEDES-BENZ	W110	190	Petrol	1959 To Fit Front
MERCEDES-BENZ	W110	190	Petrol	1960 To Fit Front

MERCEDES-BENZ	W110	190	Petrol	1961 To Fit Front
MERCEDES-BENZ	W110	190	Petrol	1962 To Fit Front
MERCEDES-BENZ	W110	190	Petrol	1963 To Fit Front
MERCEDES-BENZ	W110	190	Petrol	1964 To Fit Front
MERCEDES-BENZ	W110	190	Petrol	1965 To Fit Front
MERCEDES-BENZ	W110	200 D	Petrol	1965 To Fit Front
MERCEDES-BENZ	W110	200 D	Petrol	1966 To Fit Front
MERCEDES-BENZ	W110	200 D	Petrol	1967 To Fit Front
MERCEDES-BENZ	W110	200 D	Petrol	1968 To Fit Front
MERCEDES-BENZ	W110	200	Petrol	1965 To Fit Front
MERCEDES-BENZ	W110	200	Petrol	1966 To Fit Front
MERCEDES-BENZ	W110	200	Petrol	1967 To Fit Front
MERCEDES-BENZ	W110	200	Petrol	1968 To Fit Front
MERCEDES-BENZ	W110	230	Petrol	1965 To Fit Front
MERCEDES-BENZ	W110	230	Petrol	1966 To Fit Front
MERCEDES-BENZ	W110	230	Petrol	1967 To Fit Front
MERCEDES-BENZ	W110	230	Petrol	1968 To Fit Front
MERCEDES-BENZ	W111	220 SEb	Petrol	1959 To Fit Front
MERCEDES-BENZ	W111	220 SEb	Petrol	1960 To Fit Front
MERCEDES-BENZ	W111	220 SEb	Petrol	1961 To Fit Front
MERCEDES-BENZ	W111	220 SEb	Petrol	1962 To Fit Front
MERCEDES-BENZ	W111	220 SEb	Petrol	1963 To Fit Front
MERCEDES-BENZ	W111	220 SEb	Petrol	1964 To Fit Front
MERCEDES-BENZ	W111	220 SEb	Petrol	1965 To Fit Front
MERCEDES-BENZ	W111	220 Sb	Petrol	1959 To Fit Front
MERCEDES-BENZ	W111	220 Sb	Petrol	1960 To Fit Front
MERCEDES-BENZ	W111	220 Sb	Petrol	1961 To Fit Front
MERCEDES-BENZ	W111	220 Sb	Petrol	1962 To Fit Front
MERCEDES-BENZ	W111	220 Sb	Petrol	1963 To Fit Front
MERCEDES-BENZ	W111	220 Sb	Petrol	1964 To Fit Front
MERCEDES-BENZ	W111	220 Sb	Petrol	1965 To Fit Front
MERCEDES-BENZ	W111	220 b	Petrol	1959 To Fit Front
MERCEDES-BENZ	W111	220 b	Petrol	1960 To Fit Front
MERCEDES-BENZ	W111	220 b	Petrol	1961 To Fit Front
MERCEDES-BENZ	W111	220 b	Petrol	1962 To Fit Front
MERCEDES-BENZ	W111	220 b	Petrol	1963 To Fit Front
MERCEDES-BENZ	W111	220 b	Petrol	1964 To Fit Front
MERCEDES-BENZ	W111	220 b	Petrol	1965 To Fit Front
MERCEDES-BENZ	W111	230 S	Petrol	1965 To Fit Front
MERCEDES-BENZ	W111	230 S	Petrol	1966 To Fit Front
MERCEDES-BENZ	W111	230 S	Petrol	1967 To Fit Front

MERCEDES-BENZ	W111	230 S	Petrol	1968 To Fit Front
MERCEDES-BENZ	W111	250 SE/C	Petrol	1965 To Fit Front
MERCEDES-BENZ	W111	250 SE/C	Petrol	1966 To Fit Front
MERCEDES-BENZ	W111	250 SE/C	Petrol	1967 To Fit Front
MERCEDES-BENZ	W111	250 SE/C	Petrol	1968 To Fit Front
MERCEDES-BENZ	W111	250 SE/C	Petrol	1969 To Fit Front
MERCEDES-BENZ	W111	250 SE/C	Petrol	1970 To Fit Front
MERCEDES-BENZ	W111	250 SE/C	Petrol	1971 To Fit Front
MERCEDES-BENZ	W111	250 SE/C	Petrol	1972 To Fit Front
MERCEDES-BENZ	W111	280 SE/C	Petrol	1967 To Fit Front
MERCEDES-BENZ	W111	280 SE/C	Petrol	1968 To Fit Front
MERCEDES-BENZ	W111	280 SE/C	Petrol	1969 To Fit Front
MERCEDES-BENZ	W111	280 SE/C	Petrol	1970 To Fit Front
MERCEDES-BENZ	W111	280 SE/C	Petrol	1971 To Fit Front
MERCEDES-BENZ	W111	280 SE/C	3.50 Petrol	1969 To Fit Front
MERCEDES-BENZ	W111	280 SE/C	3.50 Petrol	1970 To Fit Front
MERCEDES-BENZ	W111	280 SE/C	3.50 Petrol	1971 To Fit Front
MERCEDES-BENZ	W112	300 SE	Petrol	1964 To Fit Front
MERCEDES-BENZ	W112	300 SE	Petrol	1965 To Fit Front
MERCEDES-BENZ	W112	300 Sec	Petrol	1964 To Fit Front
MERCEDES-BENZ	W112	300 Sec	Petrol	1965 To Fit Front
MERCEDES-BENZ	W113	230 SL	Petrol	1963 To Fit Front
MERCEDES-BENZ	W113	230 SL	Petrol	1964 To Fit Front
MERCEDES-BENZ	W113	230 SL	Petrol	1965 To Fit Front
MERCEDES-BENZ	W113	250SL	Petrol	1966 To Fit Front
MERCEDES-BENZ	W113	250SL	Petrol	1967 To Fit Front
MERCEDES-BENZ	W113	250SL	Petrol	1968 To Fit Front
MERCEDES-BENZ	W113	280 SL	Petrol	1967 To Fit Front
MERCEDES-BENZ	W113	280 SL	Petrol	1968 To Fit Front
MERCEDES-BENZ	W113	280 SL	Petrol	1969 To Fit Front
MERCEDES-BENZ	W113	280 SL	Petrol	1970 To Fit Front
MERCEDES-BENZ	W113	280 SL	Petrol	1971 To Fit Front
MERCEDES-BENZ	W114	230.6	Petrol	1967 To Fit Front
MERCEDES-BENZ	W114	230.6	Petrol	1968 To Fit Front
MERCEDES-BENZ	W114	230.6	Petrol	1969 To Fit Front
MERCEDES-BENZ	W114	230.6	Petrol	1970 To Fit Front
MERCEDES-BENZ	W114	230.6	Petrol	1971 To Fit Front
MERCEDES-BENZ	W114	250 C	Petrol	1968 To Fit Front
MERCEDES-BENZ	W114	250 C	Petrol	1969 To Fit Front
MERCEDES-BENZ	W114	250 C	Petrol	1970 To Fit Front
MERCEDES-BENZ	W114	250 C	Petrol	1971 To Fit Front

MERCEDES-BENZ	W114	250 CE	Petrol	1968 To Fit Front
MERCEDES-BENZ	W114	250 CE	Petrol	1969 To Fit Front
MERCEDES-BENZ	W114	250 CE	Petrol	1970 To Fit Front
MERCEDES-BENZ	W114	250 CE	Petrol	1971 To Fit Front
MERCEDES-BENZ	W114	250	Petrol	1967 To Fit Front
MERCEDES-BENZ	W114	250	Petrol	1968 To Fit Front
MERCEDES-BENZ	W114	250	Petrol	1969 To Fit Front
MERCEDES-BENZ	W114	250	Petrol	1970 To Fit Front
MERCEDES-BENZ	W114	250	Petrol	1971 To Fit Front
MERCEDES-BENZ	W115	200 D	Petrol	1967 To Fit Front
MERCEDES-BENZ	W115	200 D	Petrol	1968 To Fit Front
MERCEDES-BENZ	W115	200 D	Petrol	1969 To Fit Front
MERCEDES-BENZ	W115	200 D	Petrol	1970 To Fit Front
MERCEDES-BENZ	W115	200 D	Petrol	1971 To Fit Front
MERCEDES-BENZ	W115	200 D	Petrol	1972 To Fit Front
MERCEDES-BENZ	W115	200 D	Petrol	1973 To Fit Front
MERCEDES-BENZ	W115	200 D	Petrol	1974 To Fit Front
MERCEDES-BENZ	W115	200 D	Petrol	1975 To Fit Front
MERCEDES-BENZ	W115	200 D	Petrol	1976 To Fit Front
MERCEDES-BENZ	W115	200	Petrol	1967 To Fit Front
MERCEDES-BENZ	W115	200	Petrol	1968 To Fit Front
MERCEDES-BENZ	W115	200	Petrol	1969 To Fit Front
MERCEDES-BENZ	W115	200	Petrol	1970 To Fit Front
MERCEDES-BENZ	W115	200	Petrol	1971 To Fit Front
MERCEDES-BENZ	W115	200	Petrol	1972 To Fit Front
MERCEDES-BENZ	W115	200	Petrol	1973 To Fit Front
MERCEDES-BENZ	W115	200	Petrol	1974 To Fit Front
MERCEDES-BENZ	W115	200	Petrol	1975 To Fit Front
MERCEDES-BENZ	W115	200	Petrol	1976 To Fit Front
MERCEDES-BENZ	W115	220 D	Petrol	1967 To Fit Front
MERCEDES-BENZ	W115	220 D	Petrol	1968 To Fit Front
MERCEDES-BENZ	W115	220 D	Petrol	1969 To Fit Front
MERCEDES-BENZ	W115	220 D	Petrol	1970 To Fit Front
MERCEDES-BENZ	W115	220 D	Petrol	1971 To Fit Front
MERCEDES-BENZ	W115	220 D	Petrol	1972 To Fit Front
MERCEDES-BENZ	W115	220 D	Petrol	1973 To Fit Front
MERCEDES-BENZ	W115	220 D	Petrol	1974 To Fit Front
MERCEDES-BENZ	W115	220 D	Petrol	1975 To Fit Front
MERCEDES-BENZ	W115	220 D	Petrol	1976 To Fit Front
MERCEDES-BENZ	W115	220	Petrol	1967 To Fit Front
MERCEDES-BENZ	W115	220	Petrol	1968 To Fit Front

MERCEDES-BENZ	W115	220 Petrol	1969 To Fit Front
MERCEDES-BENZ	W115	220 Petrol	1970 To Fit Front
MERCEDES-BENZ	W115	220 Petrol	1971 To Fit Front
MERCEDES-BENZ	W115	220 Petrol	1972 To Fit Front
MERCEDES-BENZ	W115	220 Petrol	1973 To Fit Front
MERCEDES-BENZ	W115	220 Petrol	1974 To Fit Front
MERCEDES-BENZ	W115	220 Petrol	1975 To Fit Front
MERCEDES-BENZ	W115	220 Petrol	1976 To Fit Front
MERCEDES-BENZ	W115	230.4 Petrol	1973 To Fit Front
MERCEDES-BENZ	W115	230.4 Petrol	1974 To Fit Front
MERCEDES-BENZ	W115	230.4 Petrol	1975 To Fit Front
MERCEDES-BENZ	W115	230.4 Petrol	1976 To Fit Front
MERCEDES-BENZ	W115	240 D Petrol	1973 To Fit Front
MERCEDES-BENZ	W115	240 D Petrol	1974 To Fit Front
MERCEDES-BENZ	W115	240 D Petrol	1975 To Fit Front
MERCEDES-BENZ	W115	240 D Petrol	1976 To Fit Front
OPEL	Admiral	2.50 Petrol	1966 To Fit Front
OPEL	Admiral	2.50 Petrol	1967 To Fit Front
OPEL	Admiral	2.60 Petrol	1964 To Fit Front
OPEL	Admiral	2.60 Petrol	1965 To Fit Front
OPEL	Admiral	2.80 Petrol	1965 To Fit Front
OPEL	Admiral	2.80 Petrol	1966 To Fit Front
OPEL	Admiral	2.80 Petrol	1967 To Fit Front
OPEL	Admiral	2.80 Petrol	1968 To Fit Front
OPEL	Admiral	2.80 Petrol	1969 To Fit Front
OPEL	Admiral	2.80 Petrol	1970 To Fit Front
OPEL	Admiral	2.80 Petrol	1971 To Fit Front
OPEL	Admiral	2.80 Petrol	1972 To Fit Front
OPEL	Admiral	2.80 Petrol	1973 To Fit Front
OPEL	Admiral	2.80 Petrol	1974 To Fit Front
OPEL	Admiral	2.80 Petrol	1975 To Fit Front
OPEL	Admiral	2.80 Petrol	1976 To Fit Front
OPEL	Admiral	2.80 Petrol	1977 To Fit Front
OPEL	Admiral	4.60 Petrol	1965 To Fit Front
OPEL	Admiral	4.60 Petrol	1966 To Fit Front
OPEL	Admiral	4.60 Petrol	1967 To Fit Front
OPEL	Admiral	4.60 Petrol	1968 To Fit Front
OPEL	Commodore	2.20 Petrol	1967 To Fit Front
OPEL	Commodore	2.20 Petrol	1968 To Fit Front
OPEL	Commodore	2.20 Petrol	1969 To Fit Front
OPEL	Commodore	2.20 Petrol	1970 To Fit Front

OPEL	Commodore	2.20 Petrol	1971 To Fit Front
OPEL	Commodore	2.50 Petrol	1967 To Fit Front
OPEL	Commodore	2.50 Petrol	1968 To Fit Front
OPEL	Commodore	2.50 Petrol	1969 To Fit Front
OPEL	Commodore	2.50 Petrol	1970 To Fit Front
OPEL	Commodore	2.50 Petrol	1971 To Fit Front
OPEL	Commodore	2.50 Petrol	1978 To Fit Front
OPEL	Commodore	2.50 Petrol	1979 To Fit Front
OPEL	Commodore	2.50 Petrol	1980 To Fit Front
OPEL	Commodore	2.50 Petrol	1981 To Fit Front
OPEL	Commodore	2.50 Petrol	1982 To Fit Front
OPEL	Commodore	2.50 Petrol	1983 To Fit Front
OPEL	Commodore	2.80 Petrol	1967 To Fit Front
OPEL	Commodore	2.80 Petrol	1968 To Fit Front
OPEL	Commodore	2.80 Petrol	1969 To Fit Front
OPEL	Commodore	2.80 Petrol	1970 To Fit Front
OPEL	Commodore	2.80 Petrol	1971 To Fit Front
OPEL	Commodore	2.80 Petrol	1972 To Fit Front
OPEL	Commodore	2.80 Petrol	1973 To Fit Front
OPEL	Commodore	2.80 Petrol	1974 To Fit Front
OPEL	Commodore	2.80 Petrol	1975 To Fit Front
OPEL	Commodore	2.80 Petrol	1976 To Fit Front
OPEL	Commodore	2.80 Petrol	1977 To Fit Front
OPEL	Commodore	2.80 Petrol	1978 To Fit Front
OPEL	Diplomat	2.80 Petrol	1969 To Fit Front
OPEL	Diplomat	2.80 Petrol	1970 To Fit Front
OPEL	Diplomat	2.80 Petrol	1971 To Fit Front
OPEL	Diplomat	2.80 Petrol	1972 To Fit Front
OPEL	Diplomat	2.80 Petrol	1973 To Fit Front
OPEL	Diplomat	2.80 Petrol	1974 To Fit Front
OPEL	Diplomat	2.80 Petrol	1975 To Fit Front
OPEL	Diplomat	2.80 Petrol	1976 To Fit Front
OPEL	Diplomat	2.80 Petrol	1977 To Fit Front
OPEL	Diplomat	4.60 Petrol	1964 To Fit Front
OPEL	Diplomat	4.60 Petrol	1965 To Fit Front
OPEL	Diplomat	4.60 Petrol	1966 To Fit Front
OPEL	Diplomat	5.40 Petrol	1966 To Fit Front
OPEL	Diplomat	5.40 Petrol	1967 To Fit Front
OPEL	Diplomat	5.40 Petrol	1968 To Fit Front
OPEL	Diplomat	5.40 Petrol	1969 To Fit Front
OPEL	Diplomat	5.40 Petrol	1970 To Fit Front

OPEL	Diplomat	5.40 Petrol	1971 To Fit Front
OPEL	Diplomat	5.40 Petrol	1972 To Fit Front
OPEL	Diplomat	5.40 Petrol	1973 To Fit Front
OPEL	Diplomat	5.40 Petrol	1974 To Fit Front
OPEL	Diplomat	5.40 Petrol	1975 To Fit Front
OPEL	Diplomat	5.40 Petrol	1976 To Fit Front
OPEL	Diplomat	5.40 Petrol	1977 To Fit Front
OPEL	Kapitan A	2.50 Petrol	1966 To Fit Front
OPEL	Kapitan A	2.50 Petrol	1967 To Fit Front
OPEL	Kapitan A	2.60 Petrol	1964 To Fit Front
OPEL	Kapitan A	2.60 Petrol	1965 To Fit Front
OPEL	Kapitan A	2.80 Petrol	1965 To Fit Front
OPEL	Kapitan A	2.80 Petrol	1966 To Fit Front
OPEL	Kapitan A	2.80 Petrol	1967 To Fit Front
OPEL	Kapitan A	2.80 Petrol	1968 To Fit Front
OPEL	Kapitan A	4.60 Petrol	1965 To Fit Front
OPEL	Kapitan A	4.60 Petrol	1966 To Fit Front
OPEL	Kapitan A	4.60 Petrol	1967 To Fit Front
OPEL	Kapitan A	4.60 Petrol	1968 To Fit Front
OPEL	Kapitan B	2.80 Petrol	1969 To Fit Front
OPEL	Kapitan B	2.80 Petrol	1970 To Fit Front
OPEL	Monza	2.50 Petrol	1979 To Fit Front
OPEL	Monza	2.50 Petrol	1980 To Fit Front
OPEL	Monza	2.50 Petrol	1981 To Fit Front
OPEL	Monza	2.50 Petrol	1982 To Fit Front
OPEL	Monza	2.50 Petrol	1983 To Fit Front
OPEL	Monza	2.80 Petrol	1979 To Fit Front
OPEL	Monza	2.80 Petrol	1980 To Fit Front
OPEL	Monza	2.80 Petrol	1981 To Fit Front
OPEL	Monza	2.80 Petrol	1982 To Fit Front
OPEL	Monza	2.80 Petrol	1983 To Fit Front
OPEL	Monza	3.00 Petrol	1979 To Fit Front
OPEL	Monza	3.00 Petrol	1980 To Fit Front
OPEL	Monza	3.00 Petrol	1981 To Fit Front
OPEL	Monza	3.00 Petrol	1982 To Fit Front
OPEL	Monza	3.00 Petrol	1983 To Fit Front
OPEL	Ranger 2500	2.50 Petrol	1970 To Fit Front
OPEL	Ranger 2500	2.50 Petrol	1971 To Fit Front
OPEL	Ranger 2500	2.50 Petrol	1972 To Fit Front
OPEL	Ranger 2500	2.50 Petrol	1973 To Fit Front
OPEL	Ranger 2500	2.50 Petrol	1974 To Fit Front

OPEL	Ranger 2500	2.50 Petrol	1975 To Fit Front
OPEL	Ranger 2500	2.50 Petrol	1976 To Fit Front
OPEL	Ranger 2800	2.80 Petrol	1974 To Fit Front
OPEL	Ranger 2800	2.80 Petrol	1975 To Fit Front
OPEL	Ranger 2800	2.80 Petrol	1976 To Fit Front
OPEL	Rekord	1.90 Petrol	1966 To Fit Front
OPEL	Rekord	1.90 Petrol	1967 To Fit Front
OPEL	Rekord	1.90 Petrol	1968 To Fit Front
OPEL	Rekord	1.90 Petrol	1969 To Fit Front
OPEL	Senator	2.00 Petrol	1982 To Fit Front
OPEL	Senator	2.00 Petrol	1983 To Fit Front
OPEL	Senator	2.00 Petrol	1984 To Fit Front
OPEL	Senator	2.50 Petrol	1978 To Fit Front
OPEL	Senator	2.50 Petrol	1979 To Fit Front
OPEL	Senator	2.50 Petrol	1980 To Fit Front
OPEL	Senator	2.50 Petrol	1981 To Fit Front
OPEL	Senator	2.50 Petrol	1982 To Fit Front
OPEL	Senator	2.50 Petrol	1983 To Fit Front
OPEL	Senator	2.50 Petrol	1984 To Fit Front
OPEL	Senator	2.50 Petrol	1985 To Fit Front
OPEL	Senator	2.80 Petrol	1978 To Fit Front
OPEL	Senator	2.80 Petrol	1979 To Fit Front
OPEL	Senator	2.80 Petrol	1980 To Fit Front
OPEL	Senator	2.80 Petrol	1981 To Fit Front
OPEL	Senator	3.00 Petrol	1978 To Fit Front
OPEL	Senator	3.00 Petrol	1979 To Fit Front
OPEL	Senator	3.00 Petrol	1980 To Fit Front
OPEL	Senator	3.00 Petrol	1981 To Fit Front
OPEL	Senator	3.00 Petrol	1982 To Fit Front
OPEL	Senator	3.00 Petrol	1983 To Fit Front
OPEL	Senator	3.00 Petrol	1984 To Fit Front
OPEL	Senator	3.00 Petrol	1985 To Fit Front
PORSCHE	911 S	2.20 Petrol	1969 To Fit Front
PORSCHE	911 S	2.20 Petrol	1970 To Fit Front
PORSCHE	911 S	2.20 Petrol	1971 To Fit Front
PORSCHE	911 T	2.20 Petrol	1970 To Fit Front
PORSCHE	911 T	2.20 Petrol	1971 To Fit Front
PORSCHE	911 T	2.20 Petrol	1972 To Fit Front
RANGER (South Africa)	2500	2.50 Petrol	1970 To Fit Front
RANGER (South Africa)	2500	2.50 Petrol	1971 To Fit Front
RANGER (South Africa)	2500	2.50 Petrol	1972 To Fit Front

VAUXHALL	Royale		2.80 Petrol	1979 To Fit Front
VAUXHALL	Royale		2.80 Petrol	1980 To Fit Front
VAUXHALL	Royale		2.80 Petrol	1981 To Fit Front
VAUXHALL	Royale		2.80 Petrol	1982 To Fit Front
VAUXHALL	Royale		2.80 Petrol	1983 To Fit Front
VAUXHALL	Royale		3.00 Petrol	1979 To Fit Front
VAUXHALL	Royale		3.00 Petrol	1980 To Fit Front
VAUXHALL	Royale		3.00 Petrol	1981 To Fit Front
VAUXHALL	Royale		3.00 Petrol	1982 To Fit Front
VAUXHALL	Royale		3.00 Petrol	1983 To Fit Front
VAUXHALL	Senator		2.50 Petrol	1978 To Fit Front
VAUXHALL	Senator		2.50 Petrol	1979 To Fit Front
VAUXHALL	Senator		2.50 Petrol	1980 To Fit Front
VAUXHALL	Senator		2.50 Petrol	1981 To Fit Front
VAUXHALL	Senator		2.50 Petrol	1982 To Fit Front
VAUXHALL	Senator		2.50 Petrol	1983 To Fit Front
VAUXHALL	Senator		2.50 Petrol	1984 To Fit Front
VAUXHALL	Senator		2.50 Petrol	1985 To Fit Front
VAUXHALL	Senator		2.80 Petrol	1978 To Fit Front
VAUXHALL	Senator		2.80 Petrol	1979 To Fit Front
VAUXHALL	Senator		2.80 Petrol	1980 To Fit Front
VAUXHALL	Senator		2.80 Petrol	1981 To Fit Front
VAUXHALL	Senator		3.00 Petrol	1978 To Fit Front
VAUXHALL	Senator		3.00 Petrol	1979 To Fit Front
VAUXHALL	Senator		3.00 Petrol	1980 To Fit Front
VAUXHALL	Senator		3.00 Petrol	1981 To Fit Front
VAUXHALL	Senator		3.00 Petrol	1982 To Fit Front
VAUXHALL	Senator		3.00 Petrol	1983 To Fit Front
VAUXHALL	Senator		3.00 Petrol	1984 To Fit Front
VAUXHALL	Senator		3.00 Petrol	1985 To Fit Front
VAUXHALL	Viceroy		2.50 Petrol	1980 To Fit Front
VAUXHALL	Viceroy		2.50 Petrol	1981 To Fit Front
VAUXHALL	Viceroy		2.50 Petrol	1982 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T2	1.60 Petrol	1968 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T2	1.60 Petrol	1969 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T2	1.60 Petrol	1970 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T2	1.60 Petrol	1971 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T2	1.60 Petrol	1972 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T2	1.60 Petrol	1973 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T2	1.60 Petrol	1974 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T2	1.60 Petrol	1975 To Fit Front

VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T3	1.60 Petrol	1983 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T3	1.60 Petrol	1984 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T3	1.60 Petrol	1985 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T3	1.60 Petrol	1986 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T3	1.60 Turbo Diesel	1984 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T3	1.60 Turbo Diesel	1985 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T3	1.60 Turbo Diesel	1986 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T3	1.90 Petrol	1982 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T3	1.90 Petrol	1983 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T3	1.90 Petrol	1984 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T3	1.90 Petrol	1985 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T3	1.90 Petrol	1986 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T3	2.00 Petrol	1979 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T3	2.00 Petrol	1980 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T3	2.00 Petrol	1981 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T3	2.00 Petrol	1982 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T3	2.00 Petrol	1983 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T3	2.00 Petrol	1984 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T3	2.00 Petrol	1985 To Fit Front
VOLKSWAGEN COMMERCIAL	Transporter (Kombi) Camper	T3	2.00 Petrol	1986 To Fit Front
VOLKSWAGEN	Caravelle		1.60 Petrol	1982 To Fit Front
VOLKSWAGEN	Caravelle		1.60 Petrol	1983 To Fit Front
VOLKSWAGEN	Caravelle		1.60 Petrol	1984 To Fit Front
VOLKSWAGEN	Caravelle		1.60 Petrol	1985 To Fit Front
VOLKSWAGEN	Caravelle		1.90 Petrol	1982 To Fit Front
VOLKSWAGEN	Caravelle		1.90 Petrol	1983 To Fit Front
VOLKSWAGEN	Caravelle		1.90 Petrol	1984 To Fit Front
VOLKSWAGEN	Caravelle		1.90 Petrol	1985 To Fit Front

t.

www.ebcbremsen.ch