

Einbauliste von EBC DP2126 - bei Fragen wenden sie sich an www.ebcbremsen.ch; info@equipe-bachofner.ch; Telefon 052 511 18 70

DP2126 is suitable for the following vehicles...

This part will fit all of the vehicles listed below. For more detail on the position it fits on your vehicle, advice notes and further parts, select your vehicle from the list.

DP2126 eignet sich für folgende Fahrzeuge:

Dieses Teil passt auf alle unten aufgeführten Fahrzeuge. Für weitere Details zur Einbauposition an Ihrem Fahrzeug, wichtige Hinweise und ergänzende Teile wählen Sie bitte Ihr Fahrzeug aus der Liste aus.

Make	Model	Sub-Model	Engine	Valves	BHP	Year	Fitment Details
AUDI	100		1.60 Petrol			1969	To Fit Front
AUDI	100		1.60 Petrol			1970	To Fit Front
AUDI	100		1.60 Petrol			1971	To Fit Front
AUDI	100		1.60 Petrol			1972	To Fit Front
AUDI	100		1.90 Petrol			1969	To Fit Front
AUDI	100		1.90 Petrol			1970	To Fit Front
AUDI	100		1.90 Petrol			1971	To Fit Front
AUDI	100		1.90 Petrol			1972	To Fit Front
AUDI	Coupe	100S	1.90 Petrol			1972	To Fit Front
AUDI	Coupe	100S	1.90 Petrol			1973	To Fit Front
AUDI	Coupe	100S	1.90 Petrol			1974	To Fit Front
BMW	1600		1.60 Petrol		83	1964	To Fit Front
BMW	1600		1.60 Petrol		83	1965	To Fit Front
BMW	1600		1.60 Petrol		83	1966	To Fit Front
BMW	1602		1.60 Petrol		84	1969	To Fit Front
BMW	1602		1.60 Petrol		84	1970	To Fit Front
BMW	1602		1.60 Petrol		84	1971	To Fit Front
BMW	1602		1.60 Petrol		84	1972	To Fit Front
BMW	1602		1.60 Petrol		84	1973	To Fit Front
BMW	1602		1.60 Petrol		84	1974	To Fit Front
BMW	1602		1.60 Petrol		84	1975	To Fit Front
BMW	1800		1.80 Petrol		90	1964	To Fit Front
BMW	1800		1.80 Petrol		90	1965	To Fit Front
BMW	1800		1.80 Petrol		90	1966	To Fit Front
BMW	1800		1.80 Petrol		90	1967	To Fit Front
BMW	1800		1.80 Petrol		90	1968	To Fit Front
BMW	1800	Ti	1.80 Petrol		110	1963	To Fit Front
BMW	1800	Ti	1.80 Petrol		110	1964	To Fit Front
BMW	1800	Ti	1.80 Petrol		110	1965	To Fit Front
BMW	1800	Ti	1.80 Petrol		110	1966	To Fit Front
BMW	1800	Ti	1.80 Petrol		110	1967	To Fit Front
BMW	1800	Ti	1.80 Petrol		110	1968	To Fit Front

BMW	1800	Ti	1.80 Petrol	110	1969	To Fit Front
BMW	1802		1.80 Petrol		1968	To Fit Front
BMW	1802		1.80 Petrol		1969	To Fit Front
BMW	1802		1.80 Petrol		1970	To Fit Front
BMW	1802		1.80 Petrol		1971	To Fit Front
BMW	1802		1.80 Petrol		1972	To Fit Front
BMW	1802		1.80 Petrol		1973	To Fit Front
BMW	1802		1.80 Petrol		1974	To Fit Front
BMW	1802		1.80 Petrol		1975	To Fit Front
BMW	2000	Ti	2.00 Petrol		1966	To Fit Front
BMW	2000	Ti	2.00 Petrol		1967	To Fit Front
BMW	2000	Ti	2.00 Petrol		1968	To Fit Front
BMW	2000	Ti	2.00 Petrol		1969	To Fit Front
BMW	2000	Ti	2.00 Petrol		1970	To Fit Front
BMW	2000	Ti	2.00 Petrol		1971	To Fit Front
BMW	2000	Touring	2.00 Turbo Diesel		1966	To Fit Front
BMW	2000	Touring	2.00 Turbo Diesel		1967	To Fit Front
BMW	2000	Touring	2.00 Turbo Diesel		1968	To Fit Front
BMW	2000	Touring	2.00 Turbo Diesel		1969	To Fit Front
BMW	2000	Touring	2.00 Turbo Diesel		1970	To Fit Front
BMW	2000	Touring	2.00 Turbo Diesel		1971	To Fit Front
BMW	2000	Touring	2.00 Turbo Diesel		1972	To Fit Front
BMW	2000	Touring	2.00 Turbo Diesel		1973	To Fit Front
BMW	2002		2.00 Petrol	101	1970	To Fit Front
BMW	2002		2.00 Petrol	101	1971	To Fit Front
BMW	2002		2.00 Petrol	101	1972	To Fit Front
BMW	2002		2.00 Petrol	101	1973	To Fit Front
BMW	2002		2.00 Petrol	101	1974	To Fit Front
BMW	2002		2.00 Petrol	101	1975	To Fit Front
VOLKSWAGEN	K70		1.60 Petrol	75	1970	To Fit Front
VOLKSWAGEN	K70		1.60 Petrol	75	1971	To Fit Front
VOLKSWAGEN	K70		1.60 Petrol	75	1972	To Fit Front
VOLKSWAGEN	K70		1.60 Petrol	75	1973	To Fit Front
VOLKSWAGEN	K70		1.60 Petrol	75	1974	To Fit Front
VOLKSWAGEN	K70		1.60 Petrol	90	1970	To Fit Front
VOLKSWAGEN	K70		1.60 Petrol	90	1971	To Fit Front
VOLKSWAGEN	K70		1.60 Petrol	90	1972	To Fit Front
VOLKSWAGEN	K70		1.60 Petrol	90	1973	To Fit Front
VOLKSWAGEN	K70		1.80 Petrol	100	1973	To Fit Front
VOLKSWAGEN	K70		1.80 Petrol	100	1974	To Fit Front
VOLKSWAGEN	K70		1.80 Petrol	100	1975	To Fit Front